





How to clear administrator of PFP-8032?



Pongee Industries Co., Ltd.

Copyright ©Pongee Industries Co., Ltd.



FAQ: How to clear administrator of PFP-8032



The example illustrates:
When the PFP-8032 has been configured with administrator, you won't be allowed to operate any setting if you don't have fingerprint, card number or password of the administrator. The following instructions would guide to clear the administrator

Instructions: Using the attached USB cable of PFP-8032 to connect with computer

1 : If you're requested to verify manager after pressed "MENU" button, that means this reader has been configured with administrator


2 : Please get the attached USB cable (see the lower-left photo)

FAQ: How to clear administrator of PFP-8032




Instructions: Using the attached USB cable of PFP-8032 to connect with computer

3 : Use the mini-USB to connect the fingerprint reader (see the top-left photo)



4 5 : Connect the USB cable to computer and turn on the fingerprint reader. The fingerprint reader would be found correctly by the computer

FAQ: How to clear administrator of PFP-8032



Instructions: Running the attached time attendance software of PFP-8032 and add the fingerprint reader

6 : Using the attached CD to install the time attendance software and then enter the username and password for logging

Account name: system


Password: (Without entering)



7 : Select the "Device Management " from menu and then "Device Management "

FAQ: How to clear administrator of PFP-8032

Instructions: Running the attached time attendance software of PFP-8032 and add the fingerprint reader



8 : Please click " Add " to increase device

9 : Since we've using USB cable for connection, please set the device as following,
(1) Device No.: Please select the same as the fingerprint reader


*Note: the device number can be checked out from fingerprint reader by press the "MENU" button and select "Settings", "Communication Settings", "device number" setting

(2) Model: please select "PFP-8032"

(3) COM Port: please select "USB"

(4) Baud rate: Please select "115200"

Note: except via USB, you can click "Network" for setting of TCP/IP



10 : Press " Save " to save the setting

FAQ: How to clear administrator of PFP-8032

Instructions: Selecting the fingerprint reader that you want to clear the administrator

Attendance Management System

System Management Staff Management Device Management Attendance Management Report Window

Department Staff Device Holiday Holiday Allotment Shift Management Shift Pattern Shift Allotment Download Analysis Attendance Detail Report

Device Management

Add Device Modify Delete Save Cancel Close

Device No. 1 Device Name cnews Network

Model PFP-8032 Direction unknown in out

Alt Device

COM Ethernet

COM Port Com USB IP Address 192.168.0.224
(IP Address or Domain Name)

Baud rate 115200 Port No. 8005
Password

Device No.	Device Name	Model	COM Port	Baud rate	IP Address	Port No.	Password	direction
1	cnews	PFP-8032	USB	115200				0

11 : At this point, the PFP-8032 can be found in the software

Attendance Management System

System Management Staff Management Device Management Attendance Management Report


Department Staff Device Download Management Shift Pattern

Device Management
Device vs Employee
Download

12 : Select "Device Management" and then "Download"

pegasus

FAQ: How to clear administrator of PFP-8032



Instructions: Clearing administrator

13 : Tick the added device

14 : Please click the "Clear Admin" button

15 : Then you can see the message "Clear Admin - clear done", it means that the software clears the administrator completely.

